

This DIALOG CD and the Blue DIA-USB adapter are specific to each other and must be used together on the same computer in which the audit software is installed.

Before connecting the DIA-USB Adapter with the iButton reader model #DIA-BD please install the proper driver for your computer, 32 bit or 64 bit.

Next connect the DIA-USB Adapter.

Next select "setup_DiaLog" to install the DIA-LOG audit software.

NOTE: This computer will only recognize a specific DIA-USB adapter, (the light blue adapter on the end of the iButton AUDIT reader cable), that came with this software. This DIA-LOG audit software must be installed on each computer that you want to recognize, and use, this specific DIA-USB adapter.



In the event that you lose the USB adapter you must order a new adapter with the corresponding new Audit software CD and reinstall.

After installing this software and connecting the USB Adapter iButton reader, you can open the Audit program, connect an iButton FOB to the reader, then select "READ" on the Audit screen. The audit information will automatically, and quickly, download from the iButton FOB and be visible in the Audit screen.

For additional information please contact LpLOCKS or your safe provider.

www.LpLOCKS.com